

COYOTE® DOME AERIAL HANGER KIT FOR ADSS

Be sure to read and completely understand this procedure before applying product. Be sure to select the proper PREFORMED product before application.

Catalog #8003833

Feed cable straps through the base of the plastic hanger brackets, wrap around the COYOTE Dome, and secure. Install ADSS cable clamps by placing the bolts through the holes at the top of the plastic hanger brackets and through the clamp jaws. Position clamps on ADSS Dead-end or armor rods and secure by tightening nuts.



FIGURE 1: COYOTE Dome ADSS Aerial Hanger Kit for ADSS



FIGURE 2: COYOTE Dome mounted to ADSS Dead-end

SAFETY CONSIDERATIONS

This application procedure is not intended to supersede any company construction or safety standards. This procedure is offered only to illustrate safe application for the individual. **FAILURE TO FOLLOW THESE PROCEDURES MAY RESULT IN PERSONAL INJURY OR DEATH.**

Do not modify this product under any circumstances.

This product is intended for use by trained technicians only. This product should not be used by anyone who is not familiar with, and not trained to use it.

When working in the area of energized lines, extra care should be taken to prevent accidental electrical contact.

For proper performance and personal safety, be sure to select the proper size PREFORMED product before application.

PREFORMED products are precision devices. To insure proper performance, they should be stored in cartons under cover and handled carefully.



PREFORMED LINE PRODUCTS

P.O. Box 91129, Cleveland, Ohio 44101 • 440.461.5200 • www.preformed.com • e-mail: inquiries@preformed.com