



## Polymer Line Post – Tie Top


Be sure to read and completely understand this procedure before applying product. Be sure to select the proper PREFORMED™ product before installation.

### INSULIGN® Polymer Insulators – Line Post



**Step #1** Install the appropriate  $\frac{3}{4}$ " 10 UNC line post mounting stud (not supplied) into the bottom of the insulator.

- Short Shank (1-3/4") Line Post Stud
- Long Shank – Line Post Stud.



**Step #2** Install insulator onto the bracket or crossarm with the top groove of the insulator in line with the conductor.

## SAFETY CONSIDERATIONS

This application procedure is not intended to supersede any company construction or safety standards. This procedure is offered only to illustrate safe application for the individual.

**FAILURE TO FOLLOW THESE PROCEDURES MAY RESULT IN PERSONAL INJURY OR DEATH.**

This product may be removed and reinstalled during the initial installation if it is in good condition. After extended service life, it is recommended the product not be reused once removed from service.

**Do not modify this product under any circumstances.**

This product is intended for use by trained technicians only. **This product should not be used by anyone who is not familiar with, and not trained to use it.**

When working in the area of energized lines, extra care should be taken to prevent accidental electrical contact. Be sure to wear proper safety equipment per your company protocol.

For proper performance and personal safety, be sure to select the proper size PREFORMED™ product before application.

PREFORMED products are precision devices. To ensure proper performance, they should be stored in cartons under cover and handled carefully.



# PREFORMED LINE PRODUCTS