

# Side-of-Pole Mount (SPM)

**Weight:** 0.00kg

**Dimensions:** 0.00cm x 0.00cm x 0.00cm

## Description

The **Side-of-Pole Mount (SPM)** is designed to install quickly and provide a secure mounting structure for PV modules on a single pole. The module-specific design reduces the number of components and provides for an easy assembly. The SPM utilizes high strength aluminum components and corrosion resistant hardware for long term reliability. Seasonal adjustability for maximizing production is provided by several tilt-angle settings and is a one person operation.

## Features

### MAXIMUM STRENGTH - DURABLE DESIGN

- Standard mounts designed to withstand 90 MPH wind zones
- TIG welded aluminum pole channels
- 6000 series structural aluminum mounting rails
- Stainless steel module mounting hardware
- Zinc plated rack assembly hardware

### APPLICATION FLEXIBILITY

- Available in multiple sizes - supporting 1 through 4 modules
- Installs around standard 2 - 4.5" OD pipe (installer supplied)
- 30° to 60° tilt angle settings (full range)
- Mount up to 840W on a single pole

### EASE OF ASSEMBLY

- Module specific design reduces number of parts and labor
- No measuring required
- Factory set module hole placement creates uniform spacing
- Easy access bottom flange module attachment

## Documentation

## **Sell Sheet**

[Side-of-Pole Mounts](#)

## **Hardware List Pricing**

[Side-of-Pole Mount Pricing and Selection Guide](#)

## **Product Brochure**

[Quality Mounting Hardware Solutions for the PV Solar Industry](#)

## **Application Information**

[SPM Series AL-1.5 - Specifications](#)

[SPM Series AL-14 - Specifications](#)

[SPM Series AL-22 - Specifications](#)

[SPM Series AL-5 - Specifications](#)

[SPM Series AL-7 - Specifications](#)

[SPM Series PS-19 - Specifications](#)

[SPM1 Type A&B Assembly Instructions](#)

[SPM1 Type C Assembly Instructions](#)

[SPM1 Type D Assembly Instructions](#)

[SPM1 Type E-H Assembly Instructions](#)

[SPM2 Type A Assembly Instructions](#)

[SPM2 Type B Assembly Instructions](#)

[SPM2 Type C Assembly Instructions](#)

[SPM2 Type D Assembly Instructions](#)

[SPM2 Type E-H Assembly Instructions](#)

[SPM3 Type B Assembly Instructions](#)

[SPM3 Type C Assembly Instructions](#)

[SPM3 Type D Assembly Instructions](#)

[SPM3 Type E-H Assembly Instructions](#)

[SPM4 Type B Assembly Instructions](#)

[SPM4 Type C Assembly Instructions](#)

[SPM4 Type D Assembly Instructions](#)