

Spacers



SPSD

Substation Parallel Spacer Double

Part Number	Conductor Ø (mm)	Conductor Centre Spacing (mm)
SPSD-240-#	24.0	#
SPSD-263-#	26.3	#
SPSD-293-338-#	293-338	#

Part Number System

SPSD	Substation Parallel Spacer Double
293	Conductor Outer diameter
#	Conductor Spacing – (070 or 125mm)

Example: SPSD-293-070



SPST

Substation Parallel Spacer Triple

Part Number	Conductor Ø (mm)	Conductor Centre Spacing (mm)
SPST-263-#	263	#
SPST-293-338-#	293-338	#

Part Number System

SPST	Substation Parallel Spacer Triple
315	Conductor Outer Diameter
#	Conductor Spacing (070 or 125mm)

Example: SPST-293-070



SPSQ

Substation Parallel Spacer Quad

Part Number	Conductor Ø (mm)	Conductor Centre Spacing (mm)
SPSQ-293-338-#	293-338	#

Part Number System

SPSQ	Substation Parallel Spacer Quad
ø	Conductor Outer diameter
#	Conductor spacing (070 or 125mm)

Example: SPSQ-293-070



SPB

Substation Parallel Spacer Bars

Part Number	Conductor Ø (mm)	Conductor Centre Spacing (mm)
SPB-263-#	263	200
SPB-293-#	293	150 & 200
SPB-315-#	315	380 & 460
SPB-338-#	338	180 & 200

Part Number System

SPB	Spacer Bar
ø	Conductor Outer Diameter
#	Conductor Spacing

Note: Contact PLP for more available combinations