

# Top-of-Pole Mount (TPM)

**Weight:** 0.00kg

**Dimensions:** 0.00cm x 0.00cm x 0.00cm

## Description

The **Top-of-Pole Mount (TPM)** is designed to install quickly and provide a secure mounting structure for PV modules on a single pole. The module specific design reduces the number of components and provides for an easier assembly. The TPM utilizes high strength welded steel components and corrosion resistant hardware for long term flexibility. Seasonal adjustability for maximizing production is provided by six different tilt-angle settings and is a single person operation.



## Design Your Next Project

### TPM Design Tool

- Specify the proper TPM for your application.
- Includes foundation drawings and specifications.

**Get Started!**

## Features

### MAXIMUM STRENGTH - DURABLE DESIGN

- Standard mounts designed to withstand 90 MPH wind zones
- MIG welded steel strong backs and mounting sleeves
- 6000 series structural aluminum mounting rails
- Stainless steel module mounting hardware
- Zinc plated rack assembly hardware

### APPLICATION FLEXIBILITY

- Available in multiple sizes - supporting 1 through 24 modules
- Installs over standard Schedule 40 or 80 rigid steel pipe (installer supplied)
- 15° to 65° tilt angle settings (10° increments)
- Mount up to 4.1kW on a single pole

#### **OPTIONS / UPGRADES**

- High wind version - 130 MPH exposure
- Hot dip galvanized or powder coated finish on steel components
- Anodized module rails
- Stainless steel rack assembly hardware package
- Tamper-resistant module mounting hardware package

#### **Documentation**

##### **Sell Sheet**

[Top-of-Pole Mounts](#)

##### **Hardware List Pricing**

[TPM Pricing and Selection Guide --New Pricing effective January 1, 2019](#)

##### **[Request a Quote/Information](#)**

[Request for Quote Form](#)

[TPM Configuration Design Tool](#)

##### **Product Brochure**

[Quality Mounting Hardware Solutions for the PV Solar Industry](#)

##### **Application Information**

[TPM Addendum - Installing Support Bars](#)

[Top Clamping Modules TPM Rack Installation Supplement](#)

[TPM1 Type A-G Assembly Instructions](#)

[TPM1 Type H Assembly Instructions](#)

[TPM2 Type A-B Assembly Instructions](#)

[TPM2 Type C-H Assembly Instructions](#)

[TPM3 Type A-C Assembly Instructions](#)

[TPM3 Type D Assembly Instructions](#)

[TPM3 Type E-H Assembly Instructions](#)

[TPM3 for 3 Kaneka Modules Assembly Instructions](#)

[TPM4 Type A-B Assembly Instructions](#)

[TPM4 Type C Assembly Instructions](#)

[TPM4 Type D-G Assembly Instructions](#)  
[TPM4 Type H Assembly Instructions](#)  
[TPM6 Type A-E Assembly Instructions](#)  
[TPM6 Type F-G Assembly Instructions](#)  
[TPM8 Type A-B Assembly Instructions](#)  
[TPM8 Type C Assembly Instructions](#)  
[TPM8 Type D-H Assembly Instructions](#)  
[TPM9 Type C-H Assembly Instructions](#)  
[TPM10 Type A-B Assembly Instructions](#)  
[TPM10 Type C-G Assembly Instructions](#)  
[TPM10 Type H Assembly instructions](#)  
[TPM12 Type A-C Assembly Instructions](#)  
[TPM12 Type D-G Assembly Instructions](#)  
[TPM12 Type H Assembly Instructions](#)  
[TPM14 Type A-C Assembly Instructions](#)  
[TPM14 Type D-G Assembly Instructions](#)  
[TPM15 Type C-D Assembly Instructions](#)  
[TPM15 Type E-G Assembly Instructions](#)  
[TPM16 Type A-B Assembly Instructions](#)  
[TPM16 Type C Assembly Instructions](#)  
[TPM16 Type D-F Assembly Instructions](#)  
[TPM18 Type C Assembly Instructions](#)  
[TPM18 Type D-F Assembly Instructions](#)  
[TPM46 Enphase M215 Inverter on a TPM Rack](#)

## **Product Gallery**